

Dave Logosz
38478 Kickbusch Lane
Springfield, OR 97478
541-726-9722 klogosz@aol.com

Cadillacs - Packards - other Makes & Models

Hood Pad Installation Instructions

Before starting the installation, lay the pad out in a warm environment or in front of a heat source. This will remove all shipping wrinkles.

I recommend using 3M Super 77 spray adhesive to install the pad or your local trim shop will have vinyl top adhesive which works well.

You will need at least one other person to help with the installation.

Set the pad up in the hood (hood can remain on car). Get it in the position wanted and mark the outline of the pad onto the hood with yellow chalk.

Outline the chalk lines with masking tape and paper to minimize overspray.

FOLLOW THE INSTRUCTIONS ON THE CAN OF ADHESIVE EXACTLY.

I recommend doing one half of the pad at a time. Give it a few minutes drying time and then do the second half. Give a slight pull to smooth the vinyl and ease out any wrinkles.